Convertible radiator valves 338 - 401 series Thermostatic control heads

200 series











Function

The following series of convertible radiator valves are typically used for controlling the fluid in the emitters of heating systems.

These special valves can be converted from manual to thermostatic operation by simple replacement of the adjusting knob with a thermostatic control head. This means that the ambient temperature of any room in which they are installed can be constantly maintained at the set value.

The innovative 202 series thermostatic control head enables the room temperature to be controlled, showing the actual room temperature on the indicator on the front of the control head.

These valves have a special tailpiece with rubber hydraulic seal, permitting quick, safe connection to the radiator without the use of additional sealing materials.

Patent application No. MI2007U000405 (202 series)

Product range

VALVES:

For copper and plastic pipe:

338 series Angled convertible radiator valve	sizes 3/8", 1/2" radiator x 23 p.1.5 pipe
339 series Straight convertible radiator valve	sizes 1/2" radiator x 3/4" pipe sizes 3/8", 1/2" radiator x 23 p.1.5 pipe
342 series Angled radiator lockshield valve	sizes 1/2" radiator x 3/4" pipe sizes 3/8", 1/2" radiator x 23 p.1.5 pipe
343 series Straight radiator lockshield valve	sizes 1/2" radiator x 3/4" pipe sizes 3/8", 1/2" radiator x 23 p.1.5 pipe
	sizes 1/2" radiator x 3/4" pipe

For iron pipe:

401 series	Angled convertible radiator valve	sizes 3/8", 1/2", 3/4", 1" (*)
	Straight convertible radiator valve	sizes 3/8", 1/2", 3/4", 1" (*)
431 series	Angled radiator lockshield valve	sizes 3/8", 1/2", 3/4", 1" (*)
432 series	Straight radiator lockshield valve	sizes 3/8", 1/2", 3/4", 1" (*)

THERMOSTATIC CONTROL HEADS

200 series	Thermostatic control head with built-in liquid-filled sensor	adjustment scale from 0 to 5 corresponding to 0-28°C
201 series	Thermostatic control head with remote liquid-filled sensor	adjustment scale from 0 to 5 corresponding to 0-28°C
202 series	Thermostatic control with temperature indicator	adjustment scale from 0 to 5 corresponding to 0-28°C
203 series	Thermostatic control head with contact sensor for fluid temperature limitation	graduated scale 20-50°C, 40-90°C
209 series	Tamper-proof / anti-theft cap for use in public places	for 200 series control head

^{* 3/4&}quot; and 1" have tailpieces without rubber seals

Technical specifications of valves and lockshields

Material

brass EN 12165 CW617N, chrome plated Body: Obturator control stem: stainless steel Hydraulic seals: **EPDM** ABS (RAL 9010) Control knob and cap:

Performance

Medium: water, glycol solutions Max. percentage of glycol: 30% Max. differential pressure with control fitted: 1 bar 10 bar Max. working pressure: Carrier medium temperature range: 5-100°C

Adjustment range of 200/201/202 series thermostatic control heads

0	*	1	2 · ·	3	. 4	5
+						
OFF	7°C	12°C	16°C	20°C	24°C	28°C


Technical specification of 200/201/202 series thermostatic control heads

Adjustment scale:	0–5
Control temperature range:	0-28°C
Frost protection cut-in:	7°C
Max. ambient temperature:	50°C
Length of capillary pipe (201 series):	2 m
Room temperature indicator (202 series):	16-26°C

Technical specifications of 203 series thermostatic control heads


Adjustment scale:	- code 203502	20-50°C
	- code 203702	40–90°C
Max sensor tempera	ture:	100°C
Max pocket pressure):	10 bar
Length of capillary p	ipe:	2 m

Dimensions




Code	Α	В	С
338 302	3/8"	23 p.1,5	47,5
338 402	1/2"	23 p.1,5	53,5
338 452	1/2"	3/4"	53,5

Code	D	Е	E'	Mass (kg)
338 302	20,5	51,5	100	0,178
338 402	20,5	51,5	100	0,210
338 452	22,5	51,5	100	0,220




Code	Α	В	С
339 302	3/8"	23 p.1,5	47,5
339 402	1/2"	23 p.1,5	53,5
339 452	1/2"	3/4"	53,5

Code	D	E	E'	Mass (kg)
339 302	24	55	103	0,178
339 402	24	55	103	0,210
339 452	24,5	55	103	0,220




Code	Α	В	С
342 302	3/8"	23 p.1,5	47,5
342 402	1/2"	23 p.1,5	53,5
342 452	1/2"	3/4"	53,5

Code	D	E	Mass (kg)
342 302	21,5	39	0,167
342 402	21,5	39	0,225
342 452	23,5	39	0,205




Code	Code A B		С
343 302	3/8"	23 p.1,5	47,5
343 402	1/2"	23 p.1,5	53,5
343 452	1/2"	3/4"	53,5

Code	D	E	Mass (kg)
343 302	24	44,5	0,184
343 402	24	44,5	0,228
343 452	24,5	44,5	0,205




Code	Α	В	С
401 302	3/8"	3/8"	47,5
401 402	1/2"	1/2"	53,5
401 500	3/4"	3/4"	62,5
401 603	1"	1"	<i>7</i> 0,5

Code	D	E	E′	Mass (kg)
401 302	20	51,5	100	0,188
401 402	23	51,5	100	0,242
401 500	25	60,5	108	0,190
401 603	30,5	77,5	125	0,590




Code	Α	В	С	
402 302	3/8"	3/8"	21	
402 402	1/2"	1/2"	22	
402 500	3/4"	3/4"	30	
402 603	1 "	1"	38	

Code	D	E	E'	Mass (kg)	
402 302	46,5	55	103	0,188	
402 402	52	55	103	0,242	
402 500	59,5	66	112	0,190	
402 603	63,5	81,5	127,5	0,640	




Code	Α	В	С
431 302	3/8"	3/8"	47,5
431 402	1/2"	1/2"	53,5
431 503	3/4"	3/4"	62,5
431 603	1 "	1"	70,5

Code	D	E	Mass (kg)
431 302	20	38	0,182
431 402	23	38	0,237
431 503	25	47	0,360
431 603	30,5	47,5	0,590




Code	Α	В	С
432 302	3/8"	3/8" 3/8"	
432 402	1/2"	1/2"	22
432 503	3/4"	3/4"	30
432 603	1"	1"	38


Code	D	E	Mass (kg)
432 302	46,5	44,5	0,192
432 402	52	44,5	0,242
432 503	59,5	49,5	0,190
432 603	63,5	51,5	0,560




Code	Α	В	B'	Mass (kg)	
200000	30 p.1,5	80	-	0,165	
202000	30 p.1,5	_	85	0,168	



Code	Α	В	С	D	Е	Mass (kg)
201000	30 p.1,5	80	48	33	95	0,340




Code	Α	В	С	D	Е	Mass (kg)
203 502	30 p.1,5	80	48	Ø 11	158	0,300
203 702	30 p.1,5	80	48	Ø 9,5	134	0,300




Code	pocket for code				
475 002	203502				
475 003	203702				

Operating principle of thermostatic control head

The control device of the thermostatic valve is a proportional temperature regulator, composed of bellows containing a specific thermostatic liquid. As the temperature increases, the liquid increases in volume and causes the bellows to expand. As the temperature decreases the opposite process occurs; the bellows contract due to the thrust of the counter spring. The axial movements of the sensor element are transmitted to the valve actuator by means of the connecting stem, thereby adjusting the flow of medium in the heat emitter.






Construction details

Valve


The stainless steel control stem (1) has an EPDM double seal O-ring. In this way the upper portion of the headwork (2) can be replaced even with the system running.

The obturator (3) is shaped so as to optimise the hydraulic characteristics of the valve during the progressive action of opening or closing in thermostatic operation. The wide passage between the seat and obturator causes reduced head losses in manual operation.



Tailpiece with rubber seal

The radiator connection thread coupling union is equipped with a special shaped rubber ring (4). This system ensures a hydraulic seal without using additional sealing materials such as hemp or PTFE tape.



Thermostatic control head with temperature indicator, 202 series

Room temperature indicator

The room temperature indicator, mounted on the front of the thermostatic control, is of the LCD type. It highlights the actual room temperature reading in green, to enable precise regulation of the temperature to the desired value.




Pivoting system

A particular pivoting system keeps the indicator always vertical thus allowing its optimal visualization.



Thermostatic control head with remote sensor, 201 series

The use of the thermostatic head with remote sensor requires installation of the latter in accordance with the dimensions shown in the diagram.




Tamper-proof / anti-theft cap

The tamper-proof and anti-theft version of the thermostatic control head is obtained by fitting the cap code 209000 on the control knob as shown at side. It is secured with two screws equipped with a special head that can only be tightened using the special allen key code 209001.




Hydraulic characteristics


Convertible radiator valves with angled connections, 338 series and 401 series with thermostatic regulation, proportional band 2K




Convertible radiator valves with straight connections, 339 series and 402 series with thermostatic regulation, proportional band 2K




Convertible radiator valves with angled connections, 338 series and 401 series with manual regulation




Convertible radiator valves with straight connections, 339 series and 402 series with manual regulation




Lockshield valves with angled connections 3/8", 342 and 431 series




Lockshield valves with angled connections 1/2", 342 and 431 series




Lockshield valves with angled connections 3/4", 431




Lockshield valves with angled connections 1", 431 series




Lockshield valves with straight connections 3/8", 343 and 432 series




Lockshield valves with straight connections 1/2", 343 and 432 series



Lockshield valves with straight connections 3/4", 432 series



Lockshield valves with straight connections 1", 432 series



Values of nominal flow rate and equivalent lengths


COPPER PIPE								
	Rad.	Rad. Pipe		STRAIGHT		ANGLED		
TYPE	conn.	conn.	pipe (mm)	Kv _{0,01} (l/h)	le (m)	Kv _{0,01} (l/h)	le (m)	
Convertible radiator valve with manual adjustment	3/8"	23 p. 1,5	8/10	135	0,8	222	0,3	
Convertible radiator valve with manual adjustment	3/8"	23 p. 1,5	10/12	135	2,5	222	0,9	
Convertible radiator valve with manual adjustment	3/8"	23 p. 1,5	12/14	135	6,6	222	2,4	
Convertible radiator valve with manual adjustment	3/8"	23 p. 1,5	13/15	135	10,1	222	3,7	
Convertible radiator valve with manual adjustment	3/8"	23 p. 1,5	14/16	135	14,8	222	5,5	
Convertible radiator valve with manual adjustment	3/8"	23 p. 1,5	16/18	135	29,9	222	11,1	
Convertible radiator valve with manual adjustment	1/2"	23 p. 1,5	8/10	179	0,5	270	0,2	
Convertible radiator valve with manual adjustment	1/2"	23 p. 1,5	10/12	179	1,4	270	0,6	
Convertible radiator valve with manual adjustment	1/2"	23 p. 1,5	12/14	179	3,7	270	1,6	
Convertible radiator valve with manual adjustment	1/2"	23 p. 1,5	13/15	179	5,7	270	2,5	
Convertible radiator valve with manual adjustment	1/2"	23 p. 1,5	14/16	1 <i>7</i> 9	8,4	270	3,7	
Convertible radiator valve with manual adjustment	1/2"	23 p. 1,5	16/18	179	17,0	270	7,5	


STEEL PIPE									
	Rad.	Pipe	Ø int/ext	STRAIGHT		ANGLED			
TYPE	conn.	conn.	pipe	Kv _{0,01}	le	Kv _{0,01}	le		
			(mm)	(l/h)	(m)	(l/h)	(m)		
Convertible radiator valve with manual adjustment	3/8"	3/8"	12,7/16,7	135	7,2	222	2,7		
Convertible radiator valve with manual adjustment	1/2"	1/2"	16,3/21,0	179	15,3	270	6,7		
Convertible radiator valve with manual adjustment	3/4"	3/4"	21,7/26,4	258	33,2	336	19,6		
Convertible radiator valve with manual adjustment	1"	1"	27,4/33,2	443	38,5	447	37,8		


PLASTIC PIPE							
Convertible radiator valve with manual adjustment	3/8"	23 p. 1,5	8/12	135	0,8	222	0,3
Convertible radiator valve with manual adjustment	3/8"	23 p. 1,5	10/15	135	2,5	222	0,9
Convertible radiator valve with manual adjustment	3/8"	23 p. 1,5	12/16	135	6,6	222	2,4
Convertible radiator valve with manual adjustment	3/8"	23 p. 1,5	13/18	135	10,1	222	3,7
Convertible radiator valve with manual adjustment	3/8"	23 p. 1,5	14/18	135	14,8	222	5,5
Convertible radiator valve with manual adjustment	1/2"	23 p. 1,5	8/12	1 <i>7</i> 9	0,5	270	0,2
Convertible radiator valve with manual adjustment	1/2"	23 p. 1,5	10/15	179	1,4	270	0,6
Convertible radiator valve with manual adjustment	1/2"	23 p. 1,5	12/16	179	3,7	270	1,6
Convertible radiator valve with manual adjustment	1/2"	23 p. 1,5	13/18	1 <i>7</i> 9	5,7	270	2,5
Convertible radiator valve with manual adjustment	1/2"	23 p. 1,5	14/18	179	8,4	270	3,7
Convertible radiator valve with manual adjustment	1/2"	3/4"	20 est	1 <i>7</i> 9	8,4	270	3,7

Installation

The thermostatic control heads must be installed in horizontal position.







The sensible element of thermostatic control heads must never be installed in: niches, radiator cabinets, behind curtains or exposed to direct sunlight, otherwise false readings may occur.







Converting valves from manual to thermostatic control


Before installing the thermostatic control head, turn the knob to position no. 5











Locking and restricting the thermostat control temperature

Temperature restriction



1. Turn the knob to the fully open position (Pos. 5). Using a screw-driver, unlock the ring, pressing it fully towards the valve body.



2. Turn the knob to the new maximum open position required (e.g. Pos. 3). Turn the ring anti-clockwise up to the stop.




3. Re-lock the ring. The valve will now have a temperature range restriction from 0 to the set value.

Locking the temperature



1. Turn the knob to the fully open position (Pos. 5). Using a screw-driver, unlock the ring, pressing it fully towards the valve body.



2. Position the valve at the required temperature and turn the ring clockwise up to the stop.




3. Re-lock the ring. The valve will now be locked at the set temperature.

Resetting the temperature restriction and temperature lock



1. Using a screw-driver, unlock the ring, pressing it fully towards the valve body.



2. Turn the knob to the fully open position and the ring **anti-clockwise**, up to the stop. The RESET arrows will match up.



3. Re-lock the ring. The valve will now no longer have any temperature restriction or lock.

SPECIFICATION SUMMARY

338 series

Convertible radiator valve fitted for thermostatic control heads and thermo-electric actuators. Angled connections for copper and single and multilayer plastic pipes 23 p.1,5 for pipes from 10 to 18 mm, 3/4" for Ø 20 mm plastic pipes. Radiator connection 3/8" and 1/2" M with tailpiece equipped with EPDM pre-seal. Brass body. Chrome plated. Control knob white RAL 9010, for manual control, in ABS. Stainless steel control stem. Double seal on control stem with EPDM O-rings. Maximum working temperature 100°C. Maximum working pressure 10 bar.

339 series

Convertible radiator valve fitted for thermostatic control heads and thermo-electric actuators. Straight connections for copper and single and multilayer plastic pipes 23 p.1,5 for pipes from 10 to 18 mm, 3/4" for Ø 20 mm plastic pipes. Radiator connection 3/8" and 1/2" M with tailpiece equipped with EPDM pre-seal. Brass body. Chrome plated. Control knob white RAL 9010, for manual control, in ABS. Stainless steel control stem. Double seal on control stem with EPDM O-rings. Maximum working temperature 100°C. Maximum working pressure 10 bar.

342 series

Lockshield valve. Angled connections for copper and single and multilayer plastic pipes 23 p.1,5 for pipes from 10 to 18 mm, 3/4" for Ø 20 mm plastic pipes. Radiator connection 3/8" or 1/2" M with tailpiece equipped with EPDM pre-seal. Brass body. Chrome plated. Cap white RAL 9010 in ABS. Outward seal consisting of EPDM O-ring on control stem. Maximum working temperature 100°C. Maximum working pressure 10 bar.

343 series

Lockshield valve. Straight connections for copper and single and multilayer plastic pipes 23 p.1,5 for pipes from 10 to 18 mm, 3/4" for Ø 20 mm plastic pipes. Radiator connection 3/8" or 1/2" M with tailpiece equipped with EPDM pre-seal. Brass body. Chrome plated. Cap white RAL 9010 in ABS. Outward seal consisting of EPDM O-ring on control stem. Maximum working temperature 100°C. Maximum working pressure 10 bar.

401 series

Convertible radiator valve fitted for thermostatic control heads and thermo-electric actuators. Angled connections for steel pipes 3/8", 1/2", 3/4" or 1" F. Radiator connection 3/8" or 1/2" M with tailpiece equipped with EPDM pre-seal, 3/4" and 1" M with tailpiece without seal. Brass body. Chrome plated. Control knob white RAL 9010, for manual control, in ABS. Stainless steel control stem. Double seal on control stem with EPDM O-rings. Maximum working temperature 100°C. Maximum working pressure 10 bar.

402 series

Convertible radiator valve fitted for thermostatic control heads and thermo-electric actuators. Straight connections for steel pipes 3/8", 1/2", 3/4" or 1" F. Radiator connection 3/8" or 1/2" M with tailpiece equipped with EPDM pre-seal, 3/4" and 1" M with tailpiece without pre-seal. Brass body. Chrome plated. Control knob white RAL 9010, for manual control, in ABS. Stainless steel control stem. Double seal on control stem with EPDM O-rings. Maximum working temperature 100°C. Maximum working pressure 10 bar.

431 series

Lockshield valve. Angled connections for iron pipes 3/8", 1/2", 3/4" or 1" F. Radiator connection 3/8" or 1/2" M with tailpiece equipped with EPDM pre-seal, 3/4" and 1" M with tailpiece without seal. Brass body. Chrome plated. White cap RAL 9010 in ABS. Outward seal consisting of EPDM O-ring on control stem. Maximum working temperature 100°C. Maximum working pressure 10 bar.

432 series

Lockshield valve. Straight connections for iron pipes 3/8", 1/2", 3/4" or 1" F. Radiator connection 3/8" or 1/2" M with tailpiece equipped with EPDM pre-seal, 3/4" and 1" M with tailpiece without seal. Brass body. Chrome plated. White cap RAL 9010 in ABS. Outward seal consisting of EPDM O-ring on control stem. Maximum working temperature 100°C. Maximum working pressure 10 bar.

200 series

Thermostatic control head for thermostatic and convertible radiator valves. Built-in sensor with liquid-filled element. Maximum ambient temperature 50°C. Graduated scale from 0 to 5 corresponding to a temperature adjustment range from 0 to 28°C, with the possibility of locking and limiting the temperature. Frost protection cut-in at 7°C.

201 series

Thermostatic control head for thermostatic and convertible radiator valves. Remote sensor with liquid-filled element. Maximum ambient temperature 50°C. Graduated scale from 0 to 5 corresponding to a temperature adjustment range from 0 to 28°C, with the possibility of locking and limiting the temperature. Frost protection cut-in at 7°C.

202 series

Thermostatic control head for thermostatic and convertible radiator valves. Built-in sensor with liquid-filled element, with digital LCD room temperature indicator. Maximum ambient temperature 50°C. Graduated scale from 0 to 5 corresponding to a temperature adjustment range from 0 to 28°C, with the possibility of locking and limiting the temperature. Frost protection cut-in at 7°C. Room temperature display range from 16°C to 26°C.

203 series

Thermostatic control head with contact sensor, for fluid temperature limitation. Control temperature range 20–50°C (40–90°C). Maximum sensor temperature 100°C. Numbered scale, with possibility of locking and limiting the temperature. Capillary length 2 m.

209 series

Tamper-proof / anti-theft cap for thermostatic control head, for use in public places.

We reserve the right to change our products and their relevant technical data, contained in this publication, at any time and without prior notice.

