



Torneira de esquadria com filtro ANGLE VALVE with Integrated Filter

CARACTERÍSTICAS

- Torneira de esquadria com filtro integrado
- Evita a passagem de impurezas da canalização
- Protege a funcionalidade de dispositivos com cartuchos cerâmicos; recomendado para todas as torneiras e fluxómetros com sensor eletrónico
- Com filtro integrado de fácil limpeza
- Mecanismo com câmara com massa

FICHA TÉCNICA

- Fabricado em metal
- Ligação 1/2" x 3/8" com porca de latão, incluindo tubo de cobre 10 mm com adaptador de comprimento
- Rede do filtro em aço inoxidável e rede com 500µ densidade
- Caixa individual inclui espelho

FEATURES

- Angle Valve with Integrated Filter
- Prevents the Passage of Residues in Water-Pipes
- Protects Functionality of Mixing Devices with Ceramic Cartridges Strongly recommended for all Electronic Operated Sensor Valves !
- Integrated Compact Filter Unit and Easy Cleaning (Patented Technique)
- Mechanism with Grease Chamber

TECHNICAL DETAILS

- Execution in Full Metal
- Connection 1/2" x 3/8" with C.P. Brass Compression Nut incl. Length Adapter for a Copper Tube ø 10 mm
- Filter Strainer made out of Stainless Steel and Passage-Density of 500 µ
- Single Box packing incl. Rosette

Art.Nr.	Descrição / Description	Desenho / Drawing
788 38 12	Torneira de esquadria com filtro 1/2" x 3/8" Angle Valve with Filter 1/2" x 3/8"	
788 12 12	Acima descrito 1/2" x 1/2" as above, but 1/2" x 1/2", without C.P. Brass Compression Nut	

LIMPEZA FÁCIL DO FILTRO

- Fechar a torneira de esquadria para cortar fluxo de água.
- Abrir o filtro na parte da frente da torneira com uma moeda ou chave de parafusos
- Retirar para fora e lavar bem a rede de aço para retirar todas as impurezas e lixo
- Colocar novamente o filtro na torneira e apertar com uma moeda ou chave de parafusos
- Reabrir a torneira de esquadria

EASY CLEANING OF THE FILTER:

- Cut off water flow by closing the angle valve tightly
- Open filter part at the front with a coin or screwdriver
- Take out complete inner mechanism and wash out the residues caught in the strainer
- Insert the mechanism into the angle valve and close the filter part with a coin or screwdriver
- Open the angle valve for water flow

